

Remember to always store your OBD2 Shield keys in a safe place!

STEP 1

Slightly slide the locking latch into the shield, so that the front of the locking latch and the front rim of the shield are flush with one another.



STEP 2

Place the locking latch and shield up against the OBD2 Port, so that the locking latch aligns over the top knuckle on the OBD2 Port, then press the shield shut.



STEP 3

Take the locking screw and using the provided key, turn clockwise to lock the shield or counter clockwise to unlock the shield when access is needed.

